



VERMONT

CISCO 8811 USER GUIDE

A GUIDE TO UNDERSTANDING AND USING THE
FEATURES OF YOUR NEW PHONE



TABLE OF CONTENTS:

Phone Buttons

Page 3

Call Handling

Pages 4-5

Conference Calls

Page 6

Phone Features

Pages 7-8

Voicemail

Pages 9-10





CISCO 8811 PHONE BUTTONS



1. **Message (solid) and Incoming Call (flashing) Light**
2. **Display Screen** call information and feature status
3. **Programmable Feature Buttons** (left side) and **Session Buttons** (right side)
Active call: STEADY GREEN **Held call: FLASHING GREEN**
Incoming call: FLASHING AMBER **Shared Line in use: STEADY RED**
4. **Handset**
5. **Back Button** brings you to the previous screen
6. **Voicemail**
7. **Tools** change settings for phone and features
8. **Volume** (on hook) adjusts ringer (off hook) adjusts listening
9. **Directory** access personal and company lists
10. **Key Pad** alpha numeric dialing and menu choices
11. **Headset** turns on/off headset if installed
12. **Mute** turn on/off microphone (**STEADY RED** when off)
13. **Speakerphone** push to activate (**STEADY GREEN**)/deactivate
14. **Soft-keys** engages features as listed above each button and changes depending upon the phones current function. It will act as the "more" key.
15. **Navigation Pad & Select Button** scroll, select menu options
16. **Release Button** disconnects from an active call
17. **Hold Button** places an active call on hold
18. **Conference** initiate and add participants to a conference call
19. **Transfer Button** send a live call to another line





CALL HANDLING

Placing a call: There are several ways to place a call. Lift the handset, press the headset button, speaker button or **NEW CALL** soft-key.

To place another call (while the first is still active): Press the next available session button and dial the number. This will place the first call on hold automatically.

To call Emergency Services: Dial 911 or 8-911

To call any state office (local or long distance): Dial the 7-digit phone number

To place a non-SOV local call: Dial 8 + 7-digit phone number

To place a non-SOV long distance call: Dial 8 + 1 + Area Code + 7-digit phone number

To redial the last number called: Press the **REDIAL** soft-key

To place a speed dial call: While on-hook, enter the speed dial code, press **SOFT KEY 4** (to go to the next page of options), press the **SPEED DIAL** softkey

Ending A Call: Replace the handset, press the headset button, speaker button, release button, or **END CALL** soft-key.





CALL HANDLING, CONT.

Answering a call: There are several ways to place a call. Lift the handset, press the headset button, speaker button, **ANSWER** soft-key, or flashing session button.

To answer another incoming call: Press the flashing session button or the answer soft-key. This will place the first call on hold automatically.

To answer a call for a shared line: Press the ringing line button or flashing session button.

To place a call on hold: Press the **HOLD** button

To transfer a call: Press the transfer button or **TRANSFER** soft-key, dial the number, as you would call it or press an active session button (if connecting two active calls to each other). Remain on the line to be sure the call connects (this will also provide an opportunity to announce the call to the recipient, if desired), when ready to send the call press the transfer button or **TRANSFER** soft-key again.

- If no answer, busy line or wrong number dialed press the **CANCEL** soft-key, **RESUME** soft-key or the flashing session button to cancel the transfer and resume the call.

To switch back and forth between active calls: Press the **SWAP** soft-key

To transfer a call to directly to a VoIP voicemail box: Press * + 7-digit mailbox number and press the transfer button or **TRANSFER** soft-key again. This will not ring the phone, only transfer from one voicemail box to another and provide a notification to the recipient.



CONFERENCE CALLS

To place up to 6-way conference call:

- Place or answer the first call
- Press conference button or **CONFERENCE** soft-key
- Call the next participant (announce the conference, if desired)
- Press conference button or **CONFERENCE** soft-key
- To add other participants repeat the steps above

Please note; these conference calls are ad-hoc and up to 6 users is NOT guaranteed depending on available system resources. If many ad-hoc conferences are underway at the same time, the originator may not get 6 users in the conference. If this happens, using an external conference service is recommended.

To add an incoming call to an existing conference call:

- Answer the call
- Press conference button or **CONFERENCE** soft-key
- Press the **ACTIVE CALLS** soft-key
- Navigate to the held session button (conference group)
- Press conference button or **CONFERENCE** soft-key

To view the list of participants: Press the **SHOW DETAIL** soft-key.

To remove a participant: Navigate to the participant you want to remove and press the **REMOVE** soft-key.



PHONE FEATURES

Call forward all calls:

- Press **FORWARD ALL** soft-key
- Dial the number where you want all of your calls go, as you would call it or press the **MESSAGES** button if you want all calls to go straight to voicemail without ringing at the phone first.
- To turn off call forwarding all calls press the **FORWARD OFF** soft-key

Call divert (send an incoming call to voicemail):

- Press the **DECLINE** soft-key

Do not disturb (disable/enable ringer):

- Press the **DO NOT DISTURB** soft-key to turn it on or off



PHONE FEATURES, CONT.

Self Care Portal:

To customize your phone with speed dials and other options:

- Go to: <https://svt01cmp001.hcs.vermont.gov/ucmuser>
- Logon instructions are available at:
<http://dii.vermont.gov/support/telecommunications/voip>

Single Number Reach (SNR):

Activating, deactivating and scheduling SNR is performed from the [Self-Care Portal](#).

- To move an active call from your desk phone to your cell phone press the **MOBILITY** soft-key then press 1 to send the call to your cell phone.
- To move an active call (that originated as an incoming call to your desk phone) from your cell phone back to your desk phone pick up the handset and press the **PICKUP** soft-key.

Please note; SNR only works for lines it has been configured for. If this service is needed, a request will need to be submitted. (See your technical support staff in your office or visit [LANDesk](#).)



UNITY CONNECTION VOICEMAIL

MAILBOX ID: 7-Digit Extension
STARTER PIN: 1 2 3 4 5

To call Voicemail from your desk:

Press the [Messages Button](#)

Enter your [PIN](#) followed by #

To call Voicemail from an outside line:

Dial 888-445-2144

Press *

Enter your [Mailbox ID Number](#) followed by #

Enter your [PIN](#) followed by #



UNITY CONNECTION VOICEMAIL , CONT.

MAILBOX ID: 7-Digit Extension

STARTER PIN: 1 2 3 4 5

Main Menu

Press 1 to play new messages

Press 3 to review saved messages

During Message Playback:

Repeat 1	Save 2	Delete 3
Slow 4	Volume 5	Fast 6
Back 7	Pause 8	Forward 9
Cancel *	Help 0	End #

After Message Playback:

Repeat 1	Save 2	Delete 3
Reply 4	Forward 5	New 6
Back 7	8	Envelope 9
Cancel *	Help 0	End #



UNITY CONNECTION VOICEMAIL, CONT.

MAILBOX ID: 7-Digit Extension

STARTER PIN: 1 2 3 4 5

Press **2** To send a message
Record your message
Enter the extension or spell
the name of the person or
distribution list followed by **#**
Press **#** to confirm
Press **9 1** to add a name
Press **#** to send or choose
from the following:

Message Options:

Mark Urgent 1	Request Receipt 2	Mark Private 3
Set Future Delivery 4	Review Message Recording 5	Re-record Message 6
Add to Message 7	8	9
*	0	Send Message #



PERSONAL NOTES:

